HYVA ALUMINIUM OIL TANKS




SIDE MOUNTED TANK


Hyva

Page 1 / 1

type :

SM - 179L/150L - AL - MP - MR 140 18 228 150 liters





Part list

Pos.	Part no. 140 20 160	Description Mounting kit parts consisting of:	Qty.
1 2 3 4	081 02 116 140 20 300 140 20 328 140 20 320	air breather filter straps kit for two supports tank support	1 2 1 2
Spare P	arts		
Pos.	Part no.	Description	Qty.
5	081 02 117 081 02 121	air filter element	1
6 7	020 52 431	spy glass cover plate	1
8	020 52 432	gasket	1

Optional part							
Part no.	Description	Qty .					
147 80 303	return filter kit	1					

General information

Pay attention to the following points:

- Mount the tank according the mounting instructions.
- · Fill the tank with the recommended hydraulic oil to the centre of the spy glass (level indicator).
- · Change the oil once a year.
- Replace the air breather filter twice a year.
- Do not use the tank as a support or to stand on.
- Do not weld to the oil tank.

Specifications

Gross volume	:	179	Liters
Fill volume	:	165	Liters
Working volume	:	150	Liters
Weight tank	:	16	kg
Weight each support	:	10	kg
Connections	:	11⁄2"	BSPIT (Suction)
	:	3/4"	BSPIT (Valve plate)