HYVA ALUMINIUM OIL TANKS




SIDE MOUNTED TANK

Hyva


Page 1 / 1

type : part number tank :

SM - 201L/170L - AL - MP - MR 140 18 230







Part list

Pos.	Part no. 140 20 161	Description Mounting kit parts consisting of:	Qty.
1	081 02 116	air breather filter	1
2	140 20 300	straps	2
3	140 20 328	kit for two supports	1
4	140 20 321	tank support	2
Spare P Pos. 5 6 7 8	arts Part no. 081 02 117 081 02 121 020 52 431 020 52 432	Description air filter element spy glass cover plate gasket	Qty. 1 1 1

Optional	part
----------	------

Part no. 147 80 303

Description return filter kit

General information

Pay attention to the following points:

- Mount the tank according the mounting instructions.
- Fill the tank with the recommended hydraulic oil to the centre of the spy glass (level indicator).
- Change the oil once a year.
- Replace the air breather filter twice a year.
- Do not use the tank as a support or to stand on.
- Do not weld to the oil tank.

Specifications

Qty.

Gross volume	:	201	Liters
Fill volume	:	186	Liters
Working volume	:	170	Liters
Weight tank	:	17	kg
Weight each support	:	10	kg
Connections	:	11⁄2"	BSPIT (Suction)
	:	3/4"	BSPIT (Valve plate)